

CANOPY DOOR SYSTEM

Double Door and Single Door Options



WHY ADD CANOPY DOORS?

- Control access points on your tents
- Saves wear and tear on walls
- Significantly less cost compared to aluminum/glass doors
- Blocks wind and helps control temperature

PRODUCT OVERVIEW

The Single and Double Canopy Door Sets are an economical product to add a functional egress point to most any frame tent or frame structure. With a header bar (sold separately) this door can also be utilized on most pole supported tents.

The door panels are produced with a highly tensioned, replaceable fabric covering making them extremely light weight and portable. The upper door panels are clear and the bottom panels are white blackout.

Each door is equipped with an adjustable, pneumatic door closer and rigid door handle.

The bottom of the Canopy Door System frame includes adjustable and stakeable baseplates for easy leveling, squaring and securing of the door system.

This door system fits most tents with 8-10' leg height.

CONSTRUCTION

Jamb: Welded Steel

Door Frame: Welded Steel

Door Inserts: Welded Aluminum with Vinyl Panels

Hinges: Frame Integrated/Drop-In

Jamb & Frame Finish: Powder Coated Grey Gloss

PRODUCT VIDEO



See our website or our Youtube Channel for product installation information.

CALL US TODAY 800.228.3687 · AZTECTENTS.COM

AZTEC TENTS
DESIGN & PRODUCTION

THE AZTEC ADVANTAGE

MAKE A GRAND ENTRANCE.

DOUBLE DOOR

The opening size for the double door is 72" w x 81" +3"/-0"h.

The double door system includes:

- (1) Door Frame
- (1) Door Panel Left
- (1) Door Panel Right
- (2) Door Connection Brackets
- (2) Door Closer Arms
- (2) Baseplates
- (1) Transport Ground Bar



SINGLE DOOR (Left/Right)

The opening size for the single door is 36" w x 81" +3"/-0"h.


The single door system includes:

- (1) Door Frame
- (1) Door Panel Right
or Door Panel Left
- (2) Door Connection Brackets
- (1) Door Closer Arms
- (2) Baseplates
- (1) Transport Ground Bar




1. Pneumatic Door Closer 2. Adjustable door baseplate for squaring and leveling 3. Rigid steel pull handle 4. Replaceable door insert panels 5. Wall with door cutouts available. 6. Control access and traffic flow to tents.

CONFIGURATIONS




Double Door



Single Door (Left)

Hinges are positioned on the LEFT side when looking from the outside of the door.



Single Door (Right)

Hinges are positioned on the RIGHT side when looking from the outside of the door.

CALL US TODAY 800.228.3687 · AZTECTENTS.COM

AZTEC TENTS
DESIGN & PRODUCTION